

# HandySmoker™

Professional Culinary Smoke Infuser

## INSTRUCTIONS FOR USE

Congratulations on your purchase of the revolutionary new Handy Smoker! Please follow these instructions for your safety, and for truly delicious results:



**Step 1:** Remove your Handy Smoker and all accessories from the box. Open and insert four (4) AA batteries into the battery compartment, with the "-" battery terminals contacting the springs and the "+" terminals contacting the raised nodes in the compartment when closed.

**Step 2:** Stand the Handy Smoker up, and feed the rubber extension hose onto the black output nozzle as shown.

**Step 3:** Insert one of the circular mesh screens into the wood chip cup in the top of your Handy Smoker. Place a small "pinch" of wood chips into the bottom of the cup as shown.

**Step 4 (Optional):** For the fastest, easiest and best results, insert the nozzle end of the extension hose into your Handy Smoker Dome™ or a Handy Smoker Cup Cover™. Place the Dome over your plate of previously cooked food to be infused, or place the Cup Cover over your glass of whiskey or other beverage.

**Step 5:** Flip the switch on your Handy Smoker to lowest setting. The fan should start blowing air gently through the extension hose. Light the wood chips in the wood chip cup, using a wooden match or long-nosed lighter. \*BE CAREFUL AROUND OPEN FLAMES\* Smoke will begin to blow out of the extension hose.

**Step 6:** Direct smoke over the foods to be flavored, for 10-40 seconds or until the desired flavor is achieved, then turn off the Handy Smoker. If you are using the Handy Smoker Dome™ or Handy Smoker Cup Cover™, after they are filled with smoke, turn off and let stand for 10-40 seconds to achieve uniform coverage and full bodied flavor. Then uncover your food or beverage, serve and enjoy!

**Care and Maintenance:** Clean the wood chip cup and screen gently with dishwashing liquid and water after each use. Every 10 uses, wash the stainless steel portion of the Handy Smoker by hand or in the dishwasher. It can be separated from the handle by removing the silver screw just above the output nozzle. Do not submerge the plastic parts.

**Troubleshooting:** If the fan does not blow when the switch is set to low or high: Please check the batteries to be sure they are fresh, and correctly inserted.

For tips & tricks, accessories, special offers and customer service, visit:

[handysmoker.com](http://handysmoker.com)

**PLEASE NOTE:** Your Handy Smoker does NOT cook or bake food. Consumption of raw or undercooked food can be detrimental to your health.